



Ranger Wilds 40 Kit Enduro Pakcs





- The Wilderness series saddlebag is designed for extreme crossing scenarios. It features easy installation without the need for additional support brackets, and is lightweight, flexible, convenient, and reliable.
- Main materials: 1680D ballistic nylon, Hypalon, 1680D PVC waterproof mesh fabric, UTX, and aluminum alloy buckles.
- Capacity: Two main bags with a 40L capacity, plus an attachable 3L side bag.
- Compatibility: Universal installation.
- Weight: 5 kg





- 1** Zinc Alloy Snap
- 2** **3** 1-inch Aluminum Alloy Hook Buckle
- 4** 1.5-inch Aluminum Alloy Hook Buckle
- 5** Hook Nail
- 6** D-shaped Buckle
- 7** Strap Tie-down
- 8** Waterproof Storage Bags (Left and Right)
- 9** External Baskets (Left and Right)
- 10** Exhaust Heat Insulation Aluminum Plate

Step1

Attach the webbing correctly to the **1** **2** fixing points on the left and right hanging plates as shown in the illustration on the right.



Step2

The 1-inch aluminum alloy hook buckle of the rear fixing strap should be connected to the No. **3** fixing point on the central hanging plate.



Step3

The 1.5-inch aluminum alloy hook buckles on the side hanging plates should be connected to the No. **4** fixing points on the central hanging plate. (Select the fixing point from the three width settings based on the width of the rear seat of the vehicle.)



Step4

Secure the **6** D-shaped rings to a suitable position on the vehicle frame using Velcro, wrapping them 2 – 3 times. For vehicles without a rear rack, drill M8 holes in the tail plate to install the No. **5** hook nails. Then, connect the 1-inch aluminum alloy hook buckles of the hanging plate straps to the hook nails.





Step5

As shown in the diagram, thread the female buckle straps of the external basket through the reserved holes on the hanging plate in the order of 1, 2, 3, 4, and 5.



Step6

As shown in the left diagram, connect and secure the external basket to the corresponding left and right hanging plates. Pass the four 1-inch aluminum alloy hook buckles through the hanging plates and fasten them with the straps.



Step7

Insert the side buckles of the waterproof storage bag into the corresponding side buckles of the external basket. Fasten the 1.5-inch top buckle tightly for secure attachment. Each strap end features anti-flap Velcro, allowing you to roll up any excess webbing and secure it neatly with the Velcro.



Step8

The RW20 external basket features a Hypalon MOLLE structure on both sides, allowing for the optional installation of the RW3 small pouch by WestWind.



Step9

Use a zip tie to secure the No. 10 exhaust heat insulation aluminum plate between the exhaust pipe and the bottom of the bag to prevent heat damage from the exhaust.